

TASK	Telehandler					
HAZARDS	Flying debris		Heat / cold		Electricity	
	Cuts / laceration		Dust		Rollover	$\boxtimes$
	Pinch / crush		Noise / vibration		Plant interaction	$\boxtimes$
	High pressure		Kickback		Other:	
PPE REQUIRED						

## PRE-START CHECKS

- 1. Check the telehandler for any visible damage, ensuring tires are inflated and free of damage.
- 2. Complete all other pre-start checks as per manufacturer's guidelines.
- 3. Ensure all guards and covers are in place and secure.
- 4. Review the load chart to understand the weight limits and boom extension restrictions.

## SAFE OPERATING PROCEDURE

- 1. Ensure personnel are competent and authorised.
- 2. Ensure personnel are fit for duty and not impaired by drugs or alcohol.
- 3. Do not use a mobile phone while operating.
- 4. Wear your seatbelt while operating.
- 5. Operate at a safe speed and maintain exclusion zones around people, powerlines, and other hazards (use spotters if necessary).
- 6. Use smooth and steady movements when lifting, extending, or retracting the boom.
- 7. Keep the load low to the ground while transporting and raise only as necessary for placement.
- 8. Beware of uneven or sloping ground.
- 9. Never carry people or lift loads over people.
- 10. Use only suitable lifting gear and attachments.

## POST-OPERATION PROCEDURE

- 1. Ensure that the boom is fully retracted and lowered and that any attachments are securely placed on the ground.
- 2. Conduct a post-operation inspection for any new damage or issues.
- 3. Remove any debris from the telehandler that could become a hazard.
- 4. Turn off the engine, remove the key, and secure the vehicle to prevent unauthorised use.
- 5. Document and report any problems or incidents that occurred during operation.